



OPERATION INSTRUCTIONS :

LEAD POST #1 WITH MORTICE CYLINDER

- Turn the key.

INTERMEDIATE POST #3 WITH DROP BOLT AND CYLINDER

- Slide the knob down until the pin enters the floor socket.
- Turn key ¼ turn to raise the pin.

INTERMEDIATE POST #4 WITHOUT KEY CYLINDER

- PULL** and **HOLD** knob before sliding it down, the push back in place
- PULL** and **HOLD** knob before sliding it up.

END OR LEAD POST #2 WITH TOP AND BOTTOM PIN

- Slide the knob down.
- Slide the other knob upwards.
- Turn the key to release both knobs.



VRINDA INC.

www.FoldingSecurityGate.com

Phone: 1-877-874-6321

Fax: 1-877-874-6564

GRILLE MAINTENANCE:

PERIODICALLY:

- Clean the sliding grille with water and a soft non-abrasive cleaner.

ANNUALLY:

- Inspect the track to make sure that the joints are properly lined up and that no screws are loose.
- Clean inside the track and lubricate with a synthetic grease.