


Introduction

The Magnetic Switch works in conjunction with the Door/Window Sensor. You may use it as a replacement part for your current Door/Window Sensor, or you can use it as an additional item to add on to your existing Door/Window Sensor. Then you can set up these sensors to monitor 2 different places using only one transmitter.

Installation

- Installation of MS-001 to existing Skylink Security System
1. Remove one of the connection wires from the existing magnetic switch.
 2. Connect one of the wires from MS-001 to the existing magnetic switch.
 3. Use the provided wire nut to connect the two remaining wires from the MS-001 magnetic switch and the existing magnetic switch.
 4. Position the MS-001 magnetic switch to the door/window frame using either two sided tape or screws.
 5. Position the magnet on the door/window beside the magnetic switch. They should be no more than 1cm (3/8 inch) apart. When the door/window is closed, the magnets are in contact. When the door/window is opened, contact is broken and the transmitter sends a signal to the Control Panel to activate the chime or alarm.



Operation

1. Each Door/Window Sensor contains 2 parts. One is the transmitter (with the test button), the other is the actual sensor (magnetic switch).
2. Test the unit by pressing the test button on the transmitter. If the red LED light turns on, the unit is ready. Once the contact is broken, the transmitter will transmit a signal to Skylink's receiver(s).

Warranty

If, within one year from date of purchase, this product should become defective, due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

NOTE


If you would like to order Skylink's product or have difficulty getting them to work, please :

1. visit our website FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com, or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.
fax: 1-800-286-1320

Skylink will not be held liable or responsible for any misuse or application of this product other than for its intended use.



MAGNETIC SWITCH USER'S INSTRUCTIONS (Model MS-001)



© are registered trademarks of their respective corporations

CUSTOMER SERVICE
17 Sheard Avenue, Brampton,
Ontario, Canada L6Y 1J3
Email: support@skylinkhome.com
<http://www.skylinkhome.com>
P/N. 101A098-002 Rev. 2
US Patent 6243000B1
©2004 SKYLINK GROUP